CLEANING THE MBX BUCKER



The stainless steel construction and tool-less design of the Mobius MBX Bucker make cleaning a snap! Here's how we recommend doing it.



First, push the e-stop button, rotate the lockout to the off position, and unplug the machine.





Spray the chipper, rotating it to spritz all sides with cleaner, and continue spraying the interior surfaces.





Remove the stem hole dieplate from the front of the machine by unscrewing the 4 screws at the corners, then sliding the plate up and off.



Spray the two rollers.



Remove the plexi panel covering the stem chipper on the back side of the machine in the same way.



Using a mixture of SuperClean and hot water, spray both these components and let them sit.



Replace both covers.



Plug the machine in, disengage the lockout and turn it on, making sure to select 'reverse direction'

03

STEP





Allow the rollers and chipper to spin while the rest of the machine is sprayed with the cleaner to remove any plant debris and residue. You can use a soft brush to clean off any plant material that is more difficult to remove



Repeat this process on the opposite side with the chipper and plexi cover.



Turn the machine off, unplug it, and rinse it with water.





Use a soft cloth to wipe off the components



Remove the dieplate covering the rollers and rinse with water



Reinstall the covers. Wipe down the whole machine to remove any remaining water.