

CLEANING THE M210 MILL

The stainless steel construction and tool-less design of the Mobius M210 Mill make cleaning a snap! Here's how we recommend doing it.

STEP 01.



First remove the screen, impeller and collection drawer...

STEP 02.



and hit all of these parts and the main body of the machine with compressed air to get rid of as much dust and plant matter as possible.

STEP 03.



Next, spray everything down with water.

STEP 04.



Spritz with a diluted degreasing solution such as warm water and SuperClean.

STEP 05.



We recommend spraying down the impeller and screen first and letting the cleaning solution sit on these parts for a few minutes while you tend to the rest of the machine.

STEP 06.



Wipe down all surfaces with a soft cloth.

STEP 07.



Spray with water to rinse away any residue from the cleaning solution.

STEP 08.



Some material might be caked on the impeller which can be removed with a plastic scraper, and anything remaining can be wiped off. Allow parts to dry before reassembling.

Note: Allow parts to dry before reassembling.